

# BOGOTA RECESSED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Included Hardware:

- A: Luminaire
- B: Driver
- C: Mounting Plate (Optional)

## Required Tools and Hardware:

- Drywall Cutting Tool

## Ceiling Cutout Table

Luminaire	Cutout Dimension in Millimetre	Cutout Dimension in Inches
Bogota Recessed 2in	Ø74mm	Ø2.91"
Bogota Recessed 2.25in	Ø84mm	Ø3.31"
Bogota Recessed 2.75in	Ø95mm	Ø3.74"

# BOGOTA RECESSED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Instructions:

1

Turn power off.

2

Install *Mounting Plate* (C) at the location of *Luminaire* (A), then close the ceiling.

3

Cut a hole of the required dimensions, see Ceiling Cutout Table.

4

Connect *Driver* (B) to the main power line.

5

Connect *Luminaire* (A) to *Driver* (B).

6

Straighten up spring brackets and hold in place.

7

Insert *Luminaire* (A) in the hole and carefully release spring brackets.

8

Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

