

Project name

Type

QTY

BOGOTA SURFACE MOUNTED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

A: Luminaire

B: Driver

Required Tools and Hardware:

- Drywall Cutting Tool
- Drill
- Hex Key
- Screws
- Anchors (If Necessary)

Instructions:

1

Turn power off.

2

Install *Driver* (B) in desired location and bring power cord to the location of *Luminaire* (A).

3

Unscrew headless hex screw in *Luminaire's* (A).

4

Pull to separate bottom from base.

5

Securely screw bottom of *Luminaire* (A) level to the surface.

6

Cut a hole using the largest one of the base as a guide.

7

Connect *Luminaire* (A) to *Driver* (B).

8

Replace *Luminaire* (A) over base and screw back headless hex screw to secure *Luminaire* (A).

9

Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

