

CASCADA SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Driver
- C: Pre-Installed Base

Required Tools and Hardware:

- Drill
- Screws
- Anchors (If Necessary)
- Stud Finder (If Necessary)
- PVC Pipes (If Necessary)
- PVC Cement (If Necessary)
- PVC Primer (If Necessary)
- Saw (If Necessary)

Instructions:

Indoors Installation

- 1** Turn power off.
- 2** Install *Driver* (B) in desired location and bring power cord from *Driver* (B) to *Luminaire* (A).
- 3** Connect *Luminaire* (A) to *Driver* (B).
- 4** Securely screw *Pre-Installed Base* (C) to surface, using *Anchors* if necessary.
- 5** Adjust angle of *Luminaire* (A) as desired.
- 6** Turn power on.



Do not overload power unit if many *Luminaires* are connected to the same one.



CASCADA SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

Outdoors Installation

- 1 Prepare surface as needed by either installing *PVC Pipes*, drilling the necessary holes, etc. in order to protect cables from weather.
- 2 Turn power off.
- 3 Install *Driver* (B) in desired location and bring power cord from *Driver* (B) to *Luminaire* (A).
- 4 Connect *Luminaire* (A) to *Driver* (B).
- 5 Securely screw *Pre-Installed Base* (C) to surface using *Anchors* if necessary.
- 6 Adjust angle of *Luminaire* (A) as desired.
- 7 Turn power on.



Do not overload power unit if many *Luminaires* are connected to the same one.

