

PALAZO SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

A: Luminaire

B: Driver

C: Mounting Plate (Optional)

Required Tools and Hardware:

- Drywall Cutting Tool

If Trimless option:

- Drill
- Screws
- Plaster
- Drywall Taping Knife
- Paint
- Paintbrush

Ceiling Cutout Table

| Luminaire | Cutout Dimension in Millimetre | Cutout Dimension in Inches | Luminaire | Cutout Dimension in Millimetre | Cutout Dimension in Inches |
|--------------------------------------|--------------------------------|----------------------------|--------------------------------|--------------------------------|----------------------------|
| Palazo G1 with Trim | 37 x 37mm | 1.46 x 1.46" | Palazo G1 Trimless | 42 x 41mm | 1.65 x 1.61" |
| Palazo G2 with Trim | 68 x 37mm | 2.68 x 1.46" | Palazo G2 Trimless | 72 x 41mm | 2.83 x 1.61" |
| Palazo G5/WW5 with Trim | 140 x 37mm | 5.51 x 1.46" | Palazo G5/WW5 Trimless | 144 x 41mm | 5.67 x 1.61" |
| Palazo G10/WW10 Fixed with Trim | 273 x 37mm | 10.75 x 1.46" | Palazo G10/WW10 Fixed Trimless | 277 x 41mm | 10.91 x 1.61" |
| Palazo G10/WW10 Adjustable with Trim | 293 x 90mm | 11.54 x 3.54" | Palazo G10x2 | 293 x 143mm | 11.54 x 5.63" |
| Palazo G15/WW15 Fixed with Trim | 405 x 37mm | 15.94 x 1.46" | Palazo G15/WW15 Fixed Trimless | 410 x 41mm | 16.14 x 1.61" |
| Palazo G15/WW15 Adjustable with Trim | 425 x 90mm | 16.73 x 3.54" | Palazo G15x2 | 425 x 153mm | 16.73 x 6.02" |

PALAZO SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

- 1 Turn power off.
- 2 Install *Mounting Plate* (C) at the location of *Luminaire* (A), then close the ceiling.
- 3 Cut a hole of the required dimensions, see Ceiling Cutout Table.
- 4 Connect *Driver* (B) to the main power line.
- 5 Connect *Luminaire* (A) to *Driver* (B).
- 6 Straighten up spring brackets and hold in place.
- 7 Insert *Luminaire* (A) in the hole and carefully release spring brackets.
- 8 If Trimless option was ordered, go to Step 8, otherwise, installation is complete and power can be turned back on.
- 9 Turn power back on and insure all *Luminaire* (A) are functioning properly.
- 10 Securely screw Trimless Trim level to the surface.
- 11 Plaster over Trimless Trim according to manufacturer's instructions.
- 12 Once plastering is completed and dried, paint.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

