

Project name

Type

QTY

PALAZO SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

A: Luminaire

B: Driver

C: Mounting Plate (Optional)

Required Tools and Hardware:

- Drywall Cutting Tool

If Trimless option:

- Drill
- Screws
- Plaster
- Drywall Taping Knife
- Paint
- Paintbrush

Ceiling Cutout Table

Luminaire	Cutout Dimension in Millimetre	Cutout Dimension in Inches	Luminaire	Cutout Dimension in Millimetre	Cutout Dimension in Inches
Palazo G1 with Trim	37 x 37mm	1.46 x 1.46"	Palazo G1 Trimless	42 x 41mm	1.65 x 1.61"
Palazo G2 with Trim	68 x 37mm	2.68 x 1.46"	Palazo G2 Trimless	72 x 41mm	2.83 x 1.61"
Palazo G5/WW5 with Trim	140 x 37mm	5.51 x 1.46"	Palazo G5/WW5 Trimless	144 x 41mm	5.67 x 1.61"
Palazo G10/WW10 Fixed with Trim	273 x 37mm	10.75 x 1.46"	Palazo G10/WW10 Fixed Trimless	277 x 41mm	10.91 x 1.61"
Palazo G10/WW10 Adjustable with Trim	293 x 90mm	11.54 x 3.54"	Palazo G10x2	293 x 143mm	11.54 x 5.63"
Palazo G15/WW15 Fixed with Trim	405 x 37mm	15.94 x 1.46"	Palazo G15/WW15 Fixed Trimless	410 x 41mm	16.14 x 1.61"
Palazo G15/WW15 Adjustable with Trim	425 x 90mm	16.73 x 3.54"	Palazo G15x2	425 x 153mm	16.73 x 6.02"

Project name

Type

QTY

PALAZO SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

- 1 Turn power off.
- 2 Install *Mounting Plate* (C) at the location of *Luminaire* (A), then close the ceiling.
- 3 Cut a hole of the required dimensions, see Ceiling Cutout Table.
- 4 Connect *Driver* (B) to the main power line.
- 5 Connect *Luminaire* (A) to *Driver* (B).
- 6 Straighten up spring brackets and hold in place.
- 7 Insert *Luminaire* (A) in the hole and carefully release spring brackets.
- 8 If Trimless option was ordered, go to Step 8, otherwise, installation is complete and power can be turned back on.
- 9 Turn power back on and insure all *Luminaire* (A) are functioning properly.
- 10 Securely screw Trimless Trim level to the surface.
- 11 Plaster over Trimless Trim according to manufacturer's instructions.
- 12 Once plastering is completed and dried, paint.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

