

# REBENTO



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Included Hardware:

A: Luminaire

B: Driver

## Required Tools and Hardware:

- Drill
- 3mm Hex Key
- Screws
- PVC Pipes (If Necessary)
- PVC Cement (If Necessary)
- PVC Primer (If Necessary)
- Saw (If Necessary)
- Anchors (If Necessary)

## Instructions:

### Indoors Installation

**1** Turn power off.

**2** Install *Driver* (B) in desired location and bring power cord from *Driver* (B) to *Luminaire* (A).

**3** Unscrew headless hex screws at the bottom of *Luminaire* (A).

**4** Pull to separate mounting bracket from *Luminaire* (A).

**5** Connect *Luminaire* (A) to *Driver* (B).

**6** Securely screw mounting bracket to surface using *Anchors* if necessary.

**7** Insert *Luminaire* (A) on mounting bracket and tightly screw back in headless hex screws.


**8** Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.












# REBENTO

 This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Instructions:

### Outdoors Installation

-  Prepare surface as needed by either installing *PVC Pipes*, drilling the necessary holes, etc. in order to protect cables from weather.
-  Turn power off.
-  Install *Driver (B)* in desired location and bring power cord from *Driver (B)* to *Luminaire (A)*.
-  Unscrew headless hex screws at the bottom of *Luminaire (A)*.
-  Pull to separate mounting bracket from *Luminaire (A)*.
-  Connect *Luminaire (A)* to *Driver (B)*.
-  Securely screw mounting bracket to surface using *Anchors* if necessary.
-  Insert *Luminaire (A)* on mounting bracket and tightly screw back in headless hex screws.
-  Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

