

Project name**Type****QTY**

RIO



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Driver
- C: Rio Mounting Bracket
- D: Silver Set Screw (x1 per Bracket)
- E: Black Set Screws (x2 per Bracket)
- F: Washers (x2 per Bracket)
- G: Screws
- H: Anchors

Required Tools and Hardware:

- Drill
- Stud Finder (If Necessary)
- PVC Pipes (If Necessary)
- PVC Cement (If Necessary)
- PVC Primer (If Necessary)
- Saw (If Necessary)

Instructions:

Indoors Installation

- 1** Turn power off.
- 2** Install *Driver* (B) in desired location and bring power cord from *Driver* (B) to *Luminaire* (A).
- 3** Connect *Luminaire* (A) to *Driver* (B).
- 4** Measure and mark desired distance between *Rio Mounting Bracket* (C) and screw them to surface securely using *Anchors* (G).
- 5** Insert *Virta Mounting Bracket* (C) in the designated grooves underneath *Luminaire* (A).
- 6** Tighten *Silver Set Screw* (D) to hold *Rio Mounting Bracket* (C) in place.
- 7** Slip *Washer* (F) in *Black Set Screw* (E), then in the threaded holes on each side of *Rio Mounting Bracket* (C). Tighten to keep *Luminaire* (A) in the desired angle.
- 8** Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.



Project name**Type****QTY**

RIO



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

Outdoors Installation

- 1 Prepare surface as needed by either installing *PVC Pipes*, drilling the necessary holes, etc. in order to protect cables from weather.
- 2 Turn power off.
- 3 Install *Driver* (B) in desired location and bring power cord from *Driver* (B) to *Luminaire* (A).
- 4 Connect *Luminaire* (A) to *Driver* (B).
- 5 Measure and mark desired distance between *Rio Mounting Bracket* (C) and screw them to surface securely using *Anchors* (G).
- 6 Insert *Rio Mounting Bracket* (C) in the designated grooves underneath *Luminaire* (A).
- 7 Tighten *Silver Set Screw* (D) to hold *Rio Mounting Bracket* (C) in place.
- 8 Slip *Washer* (F) in *Black Set Screw* (E), then in the threaded holes on each side of *Rio Mounting Bracket* (C). Tighten to keep *Luminaire* (A) in the desired angle.
- 9 Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

