

# ZOOMBAR RECESSED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Included Hardware:

- A: Luminaire
- B: Driver
- C: Airtight Chicago Plenum (Optional)
- D: Mounting Plate (Optional)


## Required Tools and Hardware:

- Drywall Cutting Tool

## Ceiling Cutout Table

| Luminaire               | Cutout Dimension in Millimetre | Cutout Dimension in Inches |
|-------------------------|--------------------------------|----------------------------|
| Zoombar Recessed 3.75in | Ø81mm                          | Ø3.19"                     |
| Zoombar Recessed 4.25in | Ø92mm                          | Ø3.62"                     |

# ZOOMBAR RECESSED SERIES

 This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Instructions:

- 1 Turn power off.
- 2 Install *Airtight Chicago Plenum (C)* or *Mounting Plate (D)* at the location of *Luminaire (A)*, then close the ceiling.
- 3 Cut a hole of the required dimensions, see [Ceiling Cutout Table](#).
- 4 Connect *Driver (B)* to the main power line.
- 5 Connect *Luminaire (A)* to *Driver (B)*.
- 6 Straighten up spring brackets and hold in place.
- 7 Insert *Luminaire (A)* in the hole and carefully release spring brackets.
- 8 Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

