

**Project name**

**Type**

**QTY**

# ALINA MASTER SURFACE MOUNTED



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Included Hardware:

- A: Luminaire
- B: Driver
- C: Installation Kit (Optional)

## Required Tools and Hardware:

- Level
- Drywall Cutting Tool
- Drill
- Wire Connectors
- Screws
- Anchors

## Surface Cutout Table

Cutout Dimension in Millimetre	Cutout Dimension in Inches
46 x 40mm	1.81 x 1.57"

Project name

Type

QTY

# ALINA MASTER SURFACE MOUNTED



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Instructions:

**1** Turn power off.

**2** Install *Driver* (B) in desired location and bring power cord to the location of *Luminaire* (A). If necessary, cut *Driver's* (B) DC Quick Connect cable to do so.

**3** Cut a hole aligned with *Luminaire's* (A) power cord of the requirement dimensions, see [Surface Cutout Table](#).

**4** Using *Wire Connectors*, connect the stripped cables to *Driver* (B).  
**Channel 1:** Red Wire: Positive  
 Black Wire: Negative  
**Channel 2:** White Wire: Positive  
 Green Wire: Negative  
 If using only [Channel 1](#), isolate *Clear* and *Blue* Wires.

**5** If *Installation Kit* (D) is being used, screw *Pass-Through Set Screw* into *Pass-Through Wire*. Do NOT damage power cord.

**6** Securely screw *Luminaire* (A) leveled to the surface using the pre-drilled holes. Do NOT screw through the PCB. Doing so would cause significant damage.

**7** Turn power on.



Do not overload feed channel and/or power unit.

