

ALINA MASTER SURFACE MOUNTED



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Driver
- C: Installation Kit (Optional)

Required Tools and Hardware:

- Level
- Drywall Cutting Tool
- Drill
- Wire Connectors
- Screws
- Anchors

Surface Cutout Table

Cutout Dimension in Millimetre	Cutout Dimension in Inches
46 x 40mm	1.81 x 1.57"

ALINA MASTER SURFACE MOUNTED



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

1

Turn power off.

2

Install *Driver* (B) in desired location and bring power cord to the location of *Luminaire* (A). If necessary, cut *Driver's* (B) DC Quick Connect cable to do so.

3

Cut a hole aligned with *Luminaire's* (A) power cord of the requirement dimensions, see Surface Cutout Table.

4

Using *Wire Connectors*, connect the stripped cables to *Driver* (B).

Channel 1: **Red Wire:** Positive
 Green Wire: Negative

Channel 2: **Clear or White Wire:** Positive
 Blue or Black Wire: Negative

If using only Channel 1, isolate *Clear* and *Blue* or *White* and *Black* Wires.

5

If *Installation Kit* (D) is being used, screw *Pass-Through Set Screw* into *Pass-Through Wire*. Do **NOT** damage power cord.

6

Securely screw *Luminaire* (A) leveled to the surface using the pre-drilled holes. Do **NOT** screw through the PCB. Doing so would cause significant damage.

7

Turn power on.



Do not overload feed channel and/or power unit.

