ROCCO SURFACE MOUNTED

This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety.
Do not install if product appears to be damaged.

Included Hardware:

A: Luminaire

B: Rocco Mounting Bracket (If Applicable)

C: Pre-Installed 3M Tape (If Applicable)

Required Tools and Hardware:

- Driver
- Level
- Pen
- Drywall Cutting Tool

If installing with *Rocco Mounting Bracket:*

- Drill
- Measuring Tape
- Flathead Screws
- Anchors (If Necessary)

Instructions:

Rocco Mounting Bracket Installation

1 Turn power off.

2 Level and mark desired location of *Luminaire* (A).

3 Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A).

4 If necessary, cut a hole in order to pull out power cord.

5 Measure and mark desired distance between *Rocco Mounting Brackets* (B). Securely screw them in place.

6 Connect *Luminaire* (A) to *Driver*.

7 Insert *Luminaire* (A) into *Rocco Mounting Brackets* (B).

8 Turn power on.

Do **not** overload power unit if many *Luminaires* are connected to the same one.

LUMEN WARM

TOLL FREE 1 866 586 3692
TEL. 514 286 0227
info@lumenwarm.com

OFFICE AND SHOWROOM
155 Fortin Street, Suite 180, Quebec City, QC
G1M 3M2, Canada

LAST UPDATE
16 | 03 | 2022

Due to continuous improvements, the information herein may be changed without notice.

ROCCO SURFACE MOUNTED

This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety.
Do not install if product appears to be damaged.

Instructions:

3M Tape Installation

1. Turn power off.
2. Level and mark desired location of *Luminaire* (A).
3. Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A).
4. If necessary, cut a hole in order to pull out power cord.
5. Connect *Luminaire* (A) to *Driver*.
6. Remove *Adhesive's* (C) red paper liner at the back of *Luminaire* (A).
7. Apply *Luminaire* (A) at desired location.
8. Press well. For better results, press again 24 hours after installation.
9. Turn power on.

Do **not** overload power unit if many *Luminaires* are connected to the same one.

LUMEN WARM

TOLL FREE 1 866 586 3692
TEL. 514 286 0227
info@lumenwarm.com

OFFICE AND SHOWROOM
155 Fortin Street, Suite 180, Quebec City, QC
G1M 3M2, Canada

LAST UPDATE
16 | 03 | 2022

Due to continuous improvements, the information herein may be changed without notice.