

MYLA



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Myla Mounting Brackets


Required Tools and Hardware:

- Driver
- Level
- Pen
- Drywall Cutting Tool
- Drill
- Flathead Screws
- Anchors (If Necessary)

Surface Cutout Table

	Cutout Dimension in Millimetre	Cutout Dimension in Inches
Height	64mm	2.52"
Length	<i>Myla</i> Length + 4mm	<i>Myla</i> Length + 0.16"
Depth	Min. 43mm	Min. 1.70"

MYLA

 This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

- 1** Turn power off.
- 2** Level and mark desired location of *Luminaire* (A).
- 3** Cut a hole of the required dimensions, see Surface Cutout Table.
- 4** Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A).
- 5** If necessary, cut a hole in order to pull out power cord.
- 6** Securely screw *Myla Mounting Brackets* (B) in place, using anchors if necessary.
- 7** Connect *Luminaire* (A) to *Driver*.
- 8** Insert *Myla Mounting Brackets* (B) into *Luminaire's* (A) grooves for this purpose.
- 9** Turn power on.

 Do **not** overload power unit if many *Luminaires* are connected to the same one.

