

PALAZO MASTER



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Palazo Master Mounting Bracket
- C: Palazo Master Spring Bracket

Required Tools and Hardware:

- Driver
- Level
- Drywall Cutting Tool
- Pen
- Flathead Screws (For Palazo Master Mounting Bracket installation)
- Anchors (If Necessary)

Surface Cutout Table

Luminaire	Cutout Dimension in Millimetre	Cutout Dimension in Inches
Palazo Master	45mm x <i>Luminaire's</i> Length + 9mm	1.77" x <i>Luminaire's</i> Length + 0.35"

* Allow sufficient clearance at the back depending on the thickness of the drywall so that the Palazo Master's lips rest against the surface.

Supported Drywall Thicknesses

Mounting Bracket	Thicknesses in Millimetre	Thicknesses in Inches
Palazo Master Spring Bracket	<ul style="list-style-type: none"> • 12.7mm • 15.88mm • Double 15.88mm 	<ul style="list-style-type: none"> • 0.50" 1/2" • 0.63" 5/8" • Double 0.63" Double 5/8"

PALAZO MASTER



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

Palazo Master Mounting Bracket Installation

1

Turn power off.

2

Level and mark desired location of Luminaire (A).

3

Cut a hole of required dimensions, see [Surface Cutout Table](#).

4

Install Driver in desired location and bring power cord to the location of Luminaire (A).

5

Measure and mark desired distance between Palazo Master Mounting Brackets (B). Securely screw them in place.

6

Connect Luminaire (A) to Driver.

7

Insert Luminaire (A) into Palazo Master Mounting Brackets (B).

8

Turn power on.

Palazo Master Spring Bracket Installation

1

Turn power off.

2

Level and mark desired location of Luminaire (A).

3

Cut a hole of required dimensions, see [Surface Cutout Table](#).

4

Install Driver in desired location and bring power cord to the location of Luminaire (A).

5

Connect Luminaire (A) to Driver.

6

Straighten up spring brackets of Palazo Master Spring Brackets (C) and hold in place.

7

Insert Luminaire (A) in the hole and carefully release spring brackets.

8

Turn power on.



Do **not** overload power unit if many Luminaires are connected to the same one.

