

VENGA SUSPENDED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.





Included Hardware:

- A: Luminaire
- B: Canopy
- C: Pre-Installed Suspension Cable Locks
- D: Suspension Cable Anchors
- E: Suspension Cables
- F: Pass-Through Wire
- G: Pass-Through Set Screw
- H: Serrated Lock Washer
- I: Nut
- J: Threaded Tube
- K: Crossbar

Required Tools and Hardware:

- Driver
- Pen
- Laser Line Level
- Level
- Drill
- Wire Stripper
- 5/64" Hex Key
- Drywall Cutting Tool
- Cutting Pliers
- Wire Connectors
- Screws
- Anchors (If Necessary)

VENGA SUSPENDED SERIES

 This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged. 

Instructions:

- 1 Turn power off.
- 2 Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A). If necessary, cut *Driver's* DC Quick Connect cable to do so.
- 3 Measure and mark location of *Canopy* (B). It should be placed where the main power lines are as well as aligned with the *Luminaire* (A) power cord.
- 4 Prepare access to main power lines as needed.
- 5 While aligned with *Pre-Installed Suspension Cable Locks* (C), mark placement of *Suspension Cable Anchors* (D).
- 6 Unscrew *Suspension Cables* (E) from *Suspension Cable Anchors* (D) and screw *Anchors* (D) securely to surface before screwing *Suspension Cables* (E) back in place.
- 7 Insert *Suspension Cables* (E) in *Pre-Installed Suspension Cable Locks* (C) by pressing the pin down.
- 8 Adjust the length of *Suspension Cables* (E) until the desired effect is achieved, then cut excess *Suspension Cables* (D) if desired.
- 9 Insert power cord through *Pass-Through Wire* (F), *Canopy* (B), *Serrated Lock Washer* (H), *Nut* (I), *Threaded Tube* (J) and *Crossbar* (K) in this order.
- 10 Adjust power cord length between *Canopy* (B) and *Luminaire* (A). If needed, cut and strip power cord.
- 11 Using *Wire Connectors*, connect the stripped cables to *Driver*.
- 12 Screw *Threaded Tube* (J) into *Crossbar* (K).
- 13 Screw *Pass-Through Set Screw* (G) into *Pass-Through Wire* (F). Do **NOT** damage power cord.
- 14 Turn power on.

 Do **not** overload power unit if many *Luminaires* are connected to the same one. 