

# VENGA SUSPENDED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.




## Included Hardware:

- A: Luminaire
- B: Canopy
- C: Pre-Installed Suspension Cable Locks
- D: Suspension Cable Anchors
- E: Suspension Cables
- F: Pass-Through and Threaded Tube Assembly
- G: Pass-Through Set Screw
- H: Crossbar

## Required Tools and Hardware:

- Driver
- Pen
- Laser Line Level
- Level
- Drill
- Wire Stripper
- 5/64" Hex Key
- Drywall Cutting Tool
- Cutting Pliers
- Wire Connectors
- Screws
- Anchors (If Necessary)

# VENGA SUSPENDED SERIES

 This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



## Instructions:

- 1** Turn power off.
- 2** Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A).
- 3** Measure and mark location of *Canopy* (B). It should be placed where the main power lines are as well as aligned with the *Luminaire* (A) power cord.
- 4** Prepare access to main power lines as needed.
- 5** While aligned with *Pre-Installed Suspension Cable Locks* (C), mark placement of *Suspension Cable Anchors* (D).
- 6** Unscrew *Suspension Cables* (E) from *Suspension Cable Anchors* (D) and screw *Anchors* (D) securely to surface before screwing *Suspension Cables* (E) back in place.
- 7** Insert *Suspension Cables* (E) in *Pre-Installed Suspension Cable Locks* (C) through the unscrewed pin.
- 8** Adjust the length of *Suspension Cables* (E) until the desired effect is achieved, then, once the pin of the *Pre-Installed Suspension Cable Locks* (C) has been tightened, cut excess *Suspension Cables* (E) if desired.
- 9** Insert power cord through *Pass-Through and Threaded Tube Assembly* (F), *Canopy* (B) and *Crossbar* (H) in this order, *Pass-Through* first.
- 10** Adjust power cord length between *Canopy* (B) and *Luminaire* (A). If needed, cut and strip power cord.
- 11** Using *Wire Connectors*, connect the stripped cables to *Driver*.
 

<b>Channel 1:</b>	<b>Red Wire:</b> Positive
	<b>Green Wire:</b> Negative
<b>Channel 2:</b>	<b>Clear or White Wire:</b> Positive
	<b>Blue or Black Wire:</b> Negative
- 12** Screw *Threaded Tube* of the *Pass-Through and Threaded Tube Assembly* (F) into *Crossbar* (H) until *Canopy* (B) rests on the surface.
- 14** Turn power on.
- 13** Screw *Pass-Through Set Screw* (G) into *Pass-Through and Threaded Tube Assembly* (F). Do NOT damage power cord.



Do not overload power unit if many *Luminaires* are connected to the same one.

