

VENGA WALL MOUNTED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Pre-Installed Canopy

Required Tools and Hardware:

- Driver
- Pen
- Level
- Wire Connectors
- Screwdriver
- Screws
- Drill
- Anchors (If Necessary)

VENGA WALL MOUNTED SERIES



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

1

Turn power off.

2

Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A).

3

Measure and mark desired and leveled location of *Luminaire* (A).

4

Remove the back plate from the *Pre-Installed Canopy* (B) and mark the location of the holes.

5

Prepare access to main power lines as needed.

6

Securely screw the back plate on the surface.

7

Using *Wire Connectors*, connect the *Luminaire's* (A) stripped cables to *Driver*.

8

Replace the *Luminaire* (A) by aligning the *Pre-Installed Canopy* (B) with its back plate and screw back the included screws.

9

Turn power on.



Do **not** overload power unit if many *Luminaires* are connected to the same one.

