

JAXSON SURFACE MOUNTED



This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Included Hardware:

- A: Luminaire
- B: Spring Bracket

Required Tools and Hardware:

- Driver
- Level
- Drywall Cutting Tool
- Pen

Surface Cutout Table


Luminaire	Cutout Dimension in Millimetre	Cutout Dimension in Inches
Jaxson Surface Mounted	20mm x <i>Luminaire's</i> Length + 9mm	0.79" x <i>Luminaire's</i> Length + 0.35"

* Allow sufficient clearance at the back depending on the thickness of the drywall so that the *Jaxson's* lips rest against the surface.

Supported Drywall Thicknesses

Mounting Bracket	Thicknesses in Millimetre	Thicknesses in Inches
Spring Bracket	<ul style="list-style-type: none"> • 12.7mm • 15.88mm • Double 15.88mm 	<ul style="list-style-type: none"> • 0.50" 1/2" • 0.63" 5/8" • Double 0.63" Double 5/8"

JAXSON SURFACE MOUNTED

 This product must be installed in accordance to the national electrical code and all applicable local codes. Failure to do so may result in serious injuries. Proper grounding is required for safety. Do not install if product appears to be damaged.



Instructions:

- 1** Turn power off.
- 2** Level and mark desired location of *Luminaire* (A).
- 3** Cut a hole of required dimensions, see [Surface Cutout Table](#).
- 4** Install *Driver* in desired location and bring power cord to the location of *Luminaire* (A). If necessary, cut the DC Quick Connect cable to make the desired connection.
- 5** Connect *Luminaire* (A) to *Driver*.
- 6** Straighten up spring brackets of *Spring Brackets* (B) and hold in place.
- 7** Insert *Luminaire* (A) in the hole and carefully release spring brackets.
- 8** Turn power on.



Do **not** overload power unit if many Luminaires are connected to the same one.

